

# MAGAZINE SHELF - ASSEMBLY INSTRUCTIONS

## 2-TIER CONFIGURATION

### IMPORTANT - FOR YOUR SAFETY

- Ensure that the floor space required for the installation is flat and level.
- Never use damaged parts.
- Test that the fixture is working properly before applying load.

### STEPS

- 1) CONNECT **BRACKETS (A)** TO THE UPRIGHTS
- 2) FIT **BASE SHELF (B)** ONTO THE **BRACKETS (A)**
- 3) POSITION **SHELF (C)** BEHIND THE **BASE SHELF (B)** AND ONTO THE **BRACKETS (A)**.
- 4) ENSURE THE FRONT OF **SHELF (C)** SLOTS INTO THE TABS ON THE REAR OF **BASE SHELF (B)**






### PARTS LIST

LETTER	DESCRIPTION	QTY
A	BRACKET	1
B	FRONT SHELF	1
C	MAIN SHELF	1
D	RISER FRONT	1

### TOOLS REQUIRED

N/A

PLEASE READ THE STEPS BELOW BEFORE COMMENCING ANY ASSEMBLY



# MAGAZINE SHELF - WEIGHT LOAD RATINGS

## 2-TIER CONFIGURATION

### IMPORTANT - FOR YOUR SAFETY

- Ensure that the floor space required for the installation is flat and level.
- Never use damaged parts.
- Test that the fixture is working properly before applying load.

### STEPS

- 1) CONNECT **BRACKETS (A)** TO THE UPRIGHTS
- 2) FIT **BASE SHELF (B)** ONTO THE **BRACKETS (A)**
- 3) POSITION **SHELF (C)** BEHIND THE **BASE SHELF (B)** AND ONTO THE **BRACKETS (A)**.
- 4) ENSURE THE FRONT OF **SHELF (C)** SLOTS INTO THE TABS ON THE REAR OF **BASE SHELF (B)**

### PARTS LIST

LETTER	DESCRIPTION	QTY
A	BRACKET	1
B	FRONT SHELF	1
C	MAIN SHELF	1
D	RISER FRONT	1

### TOOLS REQUIRED

N/A

**PLEASE READ THE STEPS BELOW BEFORE COMMENCING ANY ASSEMBLY**

## G.A

Maximum Load per level in kg					
Size \ Levels	1	2	3	4	5
600	35kg	40kg	40kg	45kg	45kg
914	35kg	40kg	40kg	45kg	45kg
1200	35kg	40kg	40kg	45kg	45kg

### CONFIGURATION HEIGHTS

